

## LARGE RADIO CONTROL

GAS +  
 GAS –  
 Engage HP pump  
 Adjust HP pump pressure  
 Engage vacuum pump  
 Reverse vacuum pump  
 Wind side-mount hose reel (release with manual side-mounted hose reel)  
 Rear suction  
 Rear discharge  
 Extend rear-mounted hose  
 Retract rear-mounted hose  
 Wind suction hose reel  
 Unwind suction hose reel  
 Spout valve / upper suction hose reel valve  
 Rotate spout / suction hose arm to R  
 Unwind side-mount hose reel or release side-mount hose reel rotation  
 Extend spout / suction hose arm  
 Retract spout / suction hose arm  
 Raise spout / suction hose arm  
 Lower spout / suction hose arm  
 Vent tank  
 Rotate spout / suction hose arm to L  
 Adjust rear-mounted hose reel speed

